



Wired Cosmic Pendant Necklace



What You Will Need

- 1 x Swarovski Cosmic Pendant
- 1mm wire
- 0.4mm wire
- 18 x Swarovski Xillion beads
- 1 x headpin
- 2 x jump rings
- Micro-fibre cord
- Box ends and clasp if required

In addition you will require cutter pliers, a pair of flat nosed pliers and a pair of round nose pliers.



Fig 1.



Fig 2.



Fig 3.



Fig 4.

1. Cut a length of wire approx 10 cm in length. The wire has a natural curve but also use your thumb to gently curve the wire round into a teardrop shape. Make a loop using your round nose pliers at each end (Fig 1)
2. Take a length of 0.4mm wire approx half a metre in length and wrap one end tightly around your teardrop 3 times to secure (Fig 2). You will need to hold tight of the other end of wire to stop it spinning as you wrap. You can trim spare wire off afterwards.
3. Add a Swarovski Xillion bead and wrap the 0.4mm wire tightly up against it 3 times, add another Xillion and wrap again 3 times (Fig 3).
4. Continue this pattern all the way around the wire teardrop making sure you keep the Xillions positioned on the outside of the wire as you add them (Fig 4).
5. Next we need to make a bail for the pendant for the Cosmic crystal. Trim the end off a headpin and bend it into a small triangle shape (Fig 5). Add this to the hole in the crystal by squeezing it through either side (Fig 6).
6. Open a jump ring and thread it onto one side of the teardrop, then thread on the bail of the crystal and then through the other side of the teardrop before closing (Fig 7).
7. Link on another jump ring and thread your micro-fibre cord through (Fig 8). Attach a clasp if required using box ends.



Fig 5.



Fig 6.



Fig 7.



Fig 8.