


SEIKO

- INSTRUCTION MANUAL
- MANUAL DE INSTRUCCIONES
- MODE D'EMPLOI
- BEDIENUNGSANLEITUNG
- 使用説明書



ENGLISH

INSTRUCTION MANUAL

LOCATIONS OF CONTROL

- S1 ALARM STOP / LIGHT / SNOOZE button
- S2 HR (Hour) / MONTH
- S3 MIN (Minute) / DATE
- S4 TIME SET / ALARM SET / CALENDAR SET / LOCK
- S5 SNOOZE / ALARM ON / ALARM OFF
- S6 12HR / 24HR / YEAR
- S7 °C / °F

POWER SOURCE

This unit uses two (2) "AA" batteries (included).

BATTERY INSTALLATION

- Slide and open the battery compartment on the rear of the unit and insert two (2) "AA" batteries following the polarity diagram.
- NOTE: remove the clear film label over the LCD panel so LCD panel is visible.
- The battery that comes with this clock when you purchase it is for factory test purposes, so the battery will not provide normal service life.

TO SET CALENDAR

Slide to CALENDAR. Press MONTH, DATE or YEAR buttons to set your desired calendar. Remark: Incorrect calendar will be **automatically adjusted** i.e. February 30 will be adjusted to February 1, April 31 will be adjusted to April 1.

TO SET TIME

Slide to TIME SET (S4), press HR (S2) or MIN (S3) button to set your desired time.

TO SET ALARM

- Slide to ALM SET (S4) position, the "ALARM" sign will appear on the display. Press HR (S2) or MIN (S3) button to set your desired alarm time.
- Slide to ALARM ON (S5) "ALARM" position, the " (●) " sign will appear on the time display. The alarm function is activated.
- Slide to SNOOZE (S5) position to activate the Snooze Alarm.

"LOCK" FUNCTION

- After you set time and alarm time, slide to the LOCK (S4) position to protect the set time and alarm time against unnecessary changes caused by touch of buttons.

USING THE SNOOZE ALARM

- Slide to SNOOZE (S5) position, the sign Zz will appear on the display. The SNOOZE function is activated. Once the alarm starts to ring, you can activate the snooze by pressing the ALM STOP/LIGHT (S1) button. The alarm will stop for 5 minutes and it will start to ring again.
- To completely stop the alarm, slide the ALARM SWITCH (S5) to the OFF position. Alarm Duration: 1 minute.

12 HR / 24 HR INTERNATIONAL TIME DISPLAY

- Simply press the 12 HR/24 HR (S6) button to choose your desired format.
- In 12 HR format, a "PM" sign will appear indicating PM hours.

USING THE SUPERGLOW BACKLIGHT

- You may check the time anytime in the dark by simply pressing the ALM STOP/LIGHT button (S1) once.
- The display will light up with a soft glow that lasts for a while. You can read the time easily and clearly.

NOTE: Frequent use of this feature will affect battery life.

TO SELECT °C OR °F TEMPERATURE READING

- Press °C/°F (S7) button to choose your desired temperature reading.

CARE OF YOUR CLOCK

- Avoid exposing your clock to extreme temperatures, water or severe shock.
- Avoid contact with any corrosive materials such as perfume, alcohol, or cleaning agents.