














YANMAR Engine & Equipment Model 4TNE88 ACG, ACGD, AD, ADEL, AGD, BEN, BUE, EACG, EAD, EAD1, EADS, EC1MC, EFL, EG1A, GR, HP, HYS, IKA, LAN, M-EK, MS, NS, NSR, NSW, PG, P2, SA, TB, TB1 Bore: 3.46 in 88.00 mm										
	Engine O/H Kit		a) Piston Kit b) Ring Set		Main Bearing		Con Rod Bearing		Thrust Washers	
<u>YOK4TNE88</u> <u>YOK4TNE88/25</u>		a) <u>Y129001-22081</u> Std. <u>Y129001-22901</u> 0.25 Use 4 b) <u>Y129001-22500</u> Std. <u>Y129001-22950</u> 0.25		<u>Y129001-02931</u> Std. <u>Y129150-02871</u> 0.25 Use 5		<u>Y129150-23601</u> Std. <u>Y129150-23611</u> 0.25 Use 4		<u>Y129150-02931</u> Set of 4		
										
1) Front Seal 2) Rear Seal		1) O/H Gasket Set 2) Head Gasket 3) Liquid Gasket 4) Rocker Cover Gasket		1) Bush, Con Rod 2) Bushing, Cam 3) Bolt, Con Rod		1) Tappet				
1) <u>Y129795-01800</u> 2) <u>Y129795-01780</u>		1) <u>YMGS4TNE88</u> 2) <u>Y129407-01340</u> 3) <u>Y977770-1207F</u> 4) <u>Y129550-11310</u>		1) <u>Y129100-23910</u> x4 2) <u>Y129795-02412</u> x1 3) <u>Y121550-23200</u> x8		1) <u>Y129150-14200</u> x8				
		Valve, Intake Valve, Exhaust		Guide, Valve 1) Intake 2) Exhaust		1) Stem Seal Int 2) Stem, Seal Exh		Spring, Valve		
<u>Y129100-11100</u> x4		<u>Y129100-11130</u> x4		1) <u>Y120130-11860</u> x4 2) <u>Y129150-11810</u> x4		1) <u>Y124460-11340</u> x4 2) <u>Y121400-11340</u> x4		<u>Y129795-11120</u> x8		
										
Thermostat		Oil Pump		Water Pump						
<u>Y129155-49801</u>		<u>Y129407-32000</u>		1) <u>Y129001-42004</u> (1) 2) <u>Y129100-42004</u> (1) 3) <u>Y129263-42000</u> (1)						

(1) Check your application for proper usage.