


To install your timber building you will need to be able to comfortably walk around each side of the building



Shed Size is the base / floor dimensions - Please allow for the overhang on the roof when calculating your shed size for a specific gap

