

AIWA

	CX-S770,V770	LCX-01	XC-777
	CX-Z700,SX-Z700	LCX-700M	XS-81M
AD-3150	CX-Z1700,XS-Z1700	LX-3,30	XS-Z85M,Z87M
AD-F270,S27	CX-ZL70(fault notes)	LX-50 cct only	XS-Z1700,CX-Z1700
AD-F360,S15,AD-R4	CX-ZL880(fault	LX-330 cct only	V-770,CP-770
60	notes)	LX-S2,20	VXT-1010 psu only
AD-F810	DX-660	MX-90	MECHS
AD-F990	DX-770	MX-1500	2ME-5
AD-R460,AD-F360	DX-990	NSX-200,230	4ZG1
AD-WX110	DX-D1	NSX-330,A92	OME-11
AD-WX220	DX-D9	NSX-800	X-3
AD-WX707	DX-M45/78/755	NSX-D7Part copy	
AD-WX727	DX-M75/76	NSX-D707	
AF-3060	DX-M90M	NSX-D909	
AF-5100H	FX-30	OVD-4A	
AF-5050	FX-R20	RX-30	
AP-2400H	FX-W990,RX-990	RX-990,FX-W990	
BX-110,MX-90	FX-W1500,MX-1500	RX-S2,20	
BX-770	GX-110, MX-90	S27,AD-F270	
CA-100	GX-770	SA-C30E	
CA-DW500	HF-750,V770	SA-C50E	
CA-DW550,NSX-200	HS-G35,330	SA-P30E	
CA-DW556	HS-G36,360	SA-P50E	
CA-W10	HS-J2,02	SD-L30E	
CA-W70	HS-J7,07,400	SD-L50E	
CP-78	HS-J150,380	SD-L80E part	
CP-88,SX-78,88	HS-J170,390,SJ25	ST-R30E	
CP-770,V-770	HS-J303,J900	ST-R50E	
CP-790,CX-790	HS-J380,J150	SX-2700	
CPD-88	HS-J390,J170	SX-N340,CX-N340	
CS-200	HS-J400,HSJ-7	SX-FN520,CX-N550	
CS-300	HS-J900,J303	SX-Z700	
CS-600	HS-P202,PC202,203	TP-25Y	
CSD-707	HS-PL50,PL505	TP-S30	
CSD-EX07,08	HS-PL55,PL555	TPR-605	
CSD-XL3	HS-PX310,PX510	TPR-646	
CSD-XL25	HS-PX327,PX527	TPR-900	
CSD-XL33	HS-RX610	TPR-901	
CSD-XR505,XW505	HS-SJ25,HS-J170	TPR-903	
CS-W220	HS-T21,210	TPR-906	
CS-W330	HS-T22,220	TPR-910	
CT-X5500,Z5500	HS-T24,240	TPR-926	
CT-X5200,Z5200	HS-T50	TPR-935	
CT-X5300	HS-T60,70	TPR-940	
CU-D80	HS-T120,150	TPR-945	
CU-D86M	HS-T170,390	TPR-950	
CX-55 fax copy	HS-T202,800	TPR-955	
CX-80M	HST-280,380	TPR-968	
CX-810	HS-T800,202	TPR-990	
CX-N340,SX-N340	HV-FX33,55,330	TX-110,MX90	
CX-N540,SX-FN550	HV-G71(fault list)	TX-1500,MX-1500	
CX-N550,SX-FN520	HV-GX150	XA-007	